


Navigation and Ancillary Information Facility

Making a CK file


October 2022



Summary

Navigation and Ancillary Information Facility


- SPICE provides means to create CK files, either by packaging orientation computed by others, or by first computing orientation within SPICE and then packaging it in a CK file
 - Packaging of <u>already existing</u> orientation data can be done in two ways:
 - » Use SPICE CK writer routines by calling them from within your own SPICEbased application
 - » Convert a text file containing orientation data to a CK using the Toolkit's msopck program
 - Computing as well as packaging orientation can be done in two ways:
 - » Use SPICE geometry routines and CK writer routines by calling them from within your own SPICE-based application
 - Constructing orientation using SPICE routines is not discussed here
 - » Convert orientation rules and schedules to a CK using the *prediCkt* program available from the NAIF website



CK Writer Routines

Navigation and Ancillary Information Facility


- The SPICE toolkit provides the following CK writer routines for the FORTRAN, C, IDL and MATLAB toolkits, respectively:
 - For Type 1 CK
 - » CKW01 / ckw01_c / cspice_ckw01
 - For Type 2 CK
 - » CKW02 / ckw02_c / cspice_ckw02
 - For Type 3 CK
 - » CKW03 / ckw03_c / cspice_ckw03
 - For Type 4 CK
 - » CKW04B, CKW04A, CKW04E (no CSPICE, Icy, or Mice wrappers)
 - For Type 5 CK
 - » CKW05 / ckw05_c (no lcy or Mice wrapper)
 - For Type 6 CK
 - » CKW06 (no CSPICE, Icy or Mice wrappers)
- Only the Type 3 writer is discussed in this tutorial
 - Writers for Types 1 and 2 have very similar interfaces
 - Types 4, 5 and 6 are are not commonly used



Type 3 Writer Example - 1

Navigation and Ancillary Information Facility


 The following C-language code fragment illustrates the creation of a Type 3 C-kernel having a single segment.



Type 3 Writer Example - 2

Navigation and Ancillary Information Facility


- handle file handle for the newly created C-kernel.
- begtim, endtim start and stop times in SCLK ticks for the segment.
- inst ID code for the instrument for which the Ckernel is being made.
- ref name of the base reference frame. Must be one known to SPICE during your program execution.
- avflag a SpiceBoolean indicating whether or not to include angular velocity in the segment.
- segid a string identifying the segment. It must be no more than 40 characters in length.



Type 3 Writer Example - 3

Navigation and Ancillary Information Facility

- nrec number of records in sclkdp, quats, and avvs.
- sclkdp monotonically increasing list of times, given in SCLK ticks, that identify when quats and avvs were sampled or calculated.
- quats a list of SPICE quaternions that rotate vectors from the base frame specified by the ref argument to the inst frame.
- avvs angular rate vectors given in the base frame specified by the ref argument.
- nints number of entries in starts.
- starts a list of SCLK ticks indicating the start of interpolation intervals. They must correspond to entries in sclkdp.




Type 3 writer - Making Up Rates

Navigation and Ancillary Information Facility

 One of the easiest ways to make up angular rates is to assume a constant rotation rate between subsequent quaternions:

• Then copy the (nrec-1) value of avvs into the last element of avvs.

- Constructing angular rates in this fashion assumes that no more than one 180-degree rotation has occurred between adjacent quaternions.
 - raxisa_c chooses the smallest angle that performs the rotation encapsulated in the input matrix.
- Other techniques exist, including differentiating quaternions. Care must be exercised when taking that approach.




MSOPCK

Navigation and Ancillary Information Facility

- msopck makes CK files from orientation data provided in a time- tagged, space-delimited table in text format
- msopck can process quaternions (SPICE and non-SPICE styles), Euler angles, or rotation matrices, tagged with UTC, SCLK, or ET time tags
- msopck requires all program directives to be provided in a setup file that follows the SPICE text kernel syntax
- msopck has a simple command line interface with the following usage

```
msopck setup_file input_data_file output_ck_file
```

 If the specified output CK already exists, new segment(s) are appended to it



MSOPCK List of Setup File Keywords

Navigation and Ancillary Information Facility


Supporting Kernels/Files

Output CK Specifications

Input data Specifications

Optional and conditional keywords are shown in green

```
LSK FILE NAME
                       = 'LSK file'
                       = 'SCLK file' (or MAKE FAKE SCLK='new SCLK file'
SCLK FILE NAME
FRAMES FILE NAME
                       = 'FRAMES file'
COMMENTS FILE NAME
                       = 'file containing comments'
PRODUCER ID
                       = 'producer group/person name'
                       = 'internal file name string'
INTERNAL FILE NAME
                       = 'segment ID string'
CK SEGMENT ID
                       = 1, 2, or 3
CK TYPE
INSTRUMENT ID
                       = CK ID
REFERENCE FRAME NAME
                       = 'reference frame name'
MAXIMUM VALID INTERVAL = interval length, seconds
                       = 'SCLK', 'UTC', 'TICKS', 'DPSCLK', or 'ET'
INPUT TIME TYPE
TIME CORRECTION
                       = bias to be applied to input times, seconds
                       = 'MSOP QUATERNIONS', 'SPICE QUATERNIONS',
INPUT DATA TYPE
                         'EULER ANGLES', or 'MATRICES'
QUATERNION NORM ERROR
                       = maximum normalization error
EULER ANGLE UNITS
                       = 'DEGREES' or 'RADIANS'
EULER ROTATIONS ORDER
                       = ( 'axis3', 'axis2', 'axis1')
EULER ROTATIONS TYPE
                       = 'BODY' or 'SPACE'
                       = 'YES', 'NO', 'MAKE UP', 'MAKE UP/NO AVERAGING'
ANGULAR RATE PRESENT
                       = 'REFERENCE' or 'INSTRUMENT'
ANGULAR RATE FRAME
ANGULAR RATE THRESHOLD
                       = ( max X rate, max Y rate, max Z rate )
OFFSET ROTATION ANGLES
                       = ( angle3, angle2, angle1)
OFFSET ROTATION AXES
                       = ( 'axis3', 'axis2', 'axis1')
                       = 'DEGREES' or 'RADIANS'
OFFSET ROTATION UNITS
                       = down sampling tolerance, radians
DOWN SAMPLE TOLERANCE
                       = 'YES' or 'NO' (default 'YES')
INCLUDE INTERVAL TABLE
CHECK TIME ORDER
                       = 'YES' or 'NO' (default 'NO')
```




MSOPCK - Input Details (1)

Navigation and Ancillary Information Facility

Four Examples

```
INPUT DATA TYPE = 'SPICE QUATERNIONS'
                  TIME1 [TIME2] QCOS QSIN1 QSIN2 QSIN3 [ARX ARY ARZ ]
Input file:
                  TIME1 [TIME2] OCOS OSIN1 OSIN2 OSIN3 [ARX ARY ARZ ]
INPUT DATA TYPE = 'MSOP QUATERNIONS'
Input file:
                  TIME1 [TIME2] -QSIN1 -QSIN2 -QSIN3 QCOS [ARX ARY ARZ ]
                        [TIME2] -OSIN1 -OSIN2 -OSIN3 OCOS [ARX ARY ARZ
INPUT DATA TYPE = 'EULER ANGLES'
Input file:
                  TIME1 [TIME2] ANG3 ANG2 ANG1 [ARX ARY ARZ
                  TIME1 [TIME2] ANG3 ANG2 ANG1 [ARX ARY ARZ ]
INPUT DATA TYPE = 'ROTATION MATRICES'
                  TIME1 [TIME2] M11 M12 M13 M21 ... M33 [ARX ARY ARZ ]
Input file:
                        [TIME2] M11 M12 M13 M21 ... M33 [ARX ARY ARZ ]
```



MSOPCK - Input Details (2)

Navigation and Ancillary Information Facility

Quaternions

- INPUT_DATA_TYPE = 'SPICE QUATERNIONS' indicates the quaternions being used follow the SPICE formation rules(*)
- INPUT_DATA_TYPE = 'MSOP QUATERNIONS' indicates the quaternions being used follow the traditional AACS formation rules(*)
 - » Normally quaternions that come in telemetry are of this type
- QUATERNION_NORM_ERROR keyword may be used to identify and filter out input records with quaternions that are not unit vectors
 - » It is set to a tolerance for comparing the norm of the input quaternion with 1

Euler angles

- All three angles must be provided
- For the angles provided on the input as

```
TIME1 [TIME2] ANG3 ANG2 ANG1 [ ARX ARY ARZ ]

and rotation axes specified in the setup as


EULER_ROTATIONS_ORDER = ( 'axis3', 'axis2', 'axis1' )
```

the matrix rotating vectors from base to the structure frame is computed as

```
Vinst = [ANG3]axis3 * [ANG2]axis2 * [ANG1]axis1 * Vref
```

Angles can be provided in degrees or radians

(*) NAIF prepared a "white paper" explaining differences between various quaternion styles:




MSOPCK - Input Details (3)

Navigation and Ancillary Information Facility

- Angular rates are an optional input. Their presence or absence must be indicated using the ANGULAR_RATE_PRESENT keyword
 - If angular rates are provided (ANGULAR_RATE_PRESENT = 'YES'), they
 must be in the form of a 3D vector expressed either in the base frame (less
 common) or instrument frame (more common)
 - » The ANGULAR_RATE_FRAME keyword must be set to indicate which of the two is used
 - If angular rates are not provided, the program can either make a CK without rates (ANGULAR_RATE_PRESENT = 'NO'), or try to compute rates from the orientation data by using a uniform rotation algorithm implemented in Type 3 CKs, either with averaging (ANGULAR_RATE_PRESENT = 'MAKE UP') or without averaging (ANGULAR_RATE_PRESENT = 'MAKE UP/NO AVERAGING') of the rates computed for adjacent orientation data points
 - ANGULAR_RATE_THRESHOLD may be used to identify and filter out input records with angular rate components that are too large to be real
- Input data can be tagged with UTC, SCLK string, SCLK ticks or ET, as specified using the INPUT_TIME_TYPE keyword

Time tags must not have embedded spaces




MSOPCK - Output Details (1)

Navigation and Ancillary Information Facility

- msopck can generate Type 1, 2, or 3 CKs
 - Type 1 is rarely used only in cases when the input contains very few data points that are far apart so that interpolation between them makes no sense
 - Type 2 is also rarely used, primarily to package orientation for spinning spacecraft
 - » Normally the input for making Type 2 CKs should contain two times and the angular rate in each record
 - Type 3 is the most commonly used type because it provides interpolation between the orientation data points stored in the CK
- Interpolation intervals are determined based on the threshold value specified in the MAXIMUM_VALID_INTERVAL keyword
 - The threshold interval is specified in units of seconds
 - A Type 3 CK will allow interpolation between all input points for which the duration between points is less than or equal to the threshold
- An additional transformation to be combined with the input attitude may be specified using OFFSET_ROTATION_* keywords
 - The convention for specification of the offset rotation angles is the same as for the input Euler angles
 - A vector defined in the base frame is first multiplied by the offset rotation


Vinst = [ROTinput] * [ROToffset] * Vref



MSOPCK - Output Details (2)

Navigation and Ancillary Information Facility


- The time tags may be adjusted by a constant value, specified in seconds, using the TIME_CORRECTION keyword
- The order of input time tags can be checked using the CHECK_TIME_ORDER keyword.
- The output CK file contains one or more CK segments
 - Multiple segments are generated if the input data volume is large and does not fit into the program's internal buffer (100,000 pointing records)
 - When the output file has many segments, each segment's start time is equal to the stop time of the previous segment, i.e. there are no gaps at the segment boundaries
- The Comment area of the output CK contains the following information:
 - Contents of a comment file, if it was specified using the COMMENT_FILE_NAME keyword
 - Contents of the setup file
 - Summary of coverage for each segment written to the file, including a table listing interpolation intervals for segments of Type 2 or 3



MSOPCK - Example (1)


Navigation and Ancillary Information Facility


```
Terminal Window
$ more msopck setup.example
MSOPCK setup for predict M'01 CK generation.
\begindata
  PRODUCER ID
            = 'NAIF/JPL'
  LSK FILE NAME = 'naif0007.tls'
  SCLK_FILE_NAME = 'ORB1_SCLKSCET.00001.tsc'
  COMMENTS FILE NAME = 'msopck comments.example'
  INTERNAL_FILE_NAME = 'sample M01 SC Orientation CK File'
  CK SEGMENT ID = 'SAMPLE M01 SC BUS ATTITUDE'
  INSTRUMENT ID = -53000
  REFERENCE FRAME NAME = 'MARSIAU'
                      = 3
  CK TYPE
  MAXIMUM VALID INTERVAL = 60
  INPUT TIME TYPE = 'SCLK'
  QUATERNION NORM ERROR = 1.0E-3
  ANGULAR RATE PRESENT = 'MAKE UP'
\begintext
```



MSOPCK - Example (2)

Navigation and Ancillary Information Facility






MSOPCK - Example (3)

Navigation and Ancillary Information Facility

		Terminal Win	dow		X
<pre>\$ more msopck_in</pre>	put.example				
0767491368.064	-0.24376335	0.68291384	0.28475901	0.62699316	
0767491372.114	-0.24249471	0.68338563	0.28591829	0.62644323	
0767491373.242	-0.24204185	0.68355329	0.28633291	0.62624605	
0767491374.064	-0.24194814	0.68358228	0.28641744	0.62621196	
0767491380.064	-0.24012676	0.68424169	0.28807922	0.62543010	
0767491386.064	-0.23830473	0.68489895	0.28973563	0.62464193	
0767491392.064	-0.23648008	0.68555126	0.29139303	0.62384833	
0767491398.064	-0.23465389	0.68620253	0.29304524	0.62304745	
0767491404.064	-0.23282999	0.68684150	0.29470173	0.62224580	
0767491404.114	-0.23277293	0.68686688	0.29475362	0.62221455	
0767491405.242	-0.23231585	0.68702790	0.29516507	0.62201253	
0767491410.064	-0.23100059	0.68748174	0.29634561	0.62143935	
0767491416.064	-0.22917353	0.68811325	0.29799308	0.62062853	
0767491422.064	-0.22734161	0.68874177	0.29963482	0.61981412	
0767491428.064	-0.22551078	0.68936246	0.30128030	0.61899473	
0767491434.064	-0.22367453	0.68998299	0.30291779	0.61816987	
0767491436.114	-0.22300583	0.69021050	0.30351804	0.61786298	
0767491438.011	-0.22251770	0.69037871	0.30395477	0.61763631	
• • •					




MSOPCK - Example (4)

Navigation and Ancillary Information Facility

	Terminal Window					
	<pre>\$ msopck msopck_setup.example msopck_input.example msopck_example_ck.bc</pre>					
	MSOPCK Utility Program, Version 3.0.0, 2003-05-05; SPICE Toolkit Ver. N0057					
	<pre><comment contents="" file=""></comment></pre>					
	<pre> <setup contents="" file=""> </setup></pre>					
	··· **********************************					
•	RUN-TIME OBTAINED META INFORMATION: ************************************					
	PRODUCT_CREATION_TIME = 2004-04-29T12:17:55					
	START_TIME = 2004-04-27T00:00:05.516					
	$STOP_TIME = 2004-04-27T23:59:56.275$					

	INTERPOLATION INTERVALS IN THE FILE SEGMENTS:					


	SEG.SUMMARY: ID -53000, COVERG: 2004-04-27T00:00:05.516 2004-04-27T23:59:56.275					
	2004-04-27T00:00:05.516 2004-04-27T20:05:26.282					
	2004-04-27T20:11:20.278 2004-04-27T23:59:56.273					



PREDICKT

Navigation and Ancillary Information Facility

- prediCkt makes CK files from a set of orientation specification rules, and schedules defining when these rules are to be followed
- prediCkt has a simple command line interface
- prediCkt requires orientation and schedule specifications to be provided in a setup file that follows the SPICE text kernel syntax
- prediCkt requires the names of all supporting kernels --SPK, PCK, etc -- be provided in a meta-kernel (a "furnsh kernel")
- prediCkt and its User Guide are available only from the Utilities link of the NAIF webpages




PREDICKT - Usage

Navigation and Ancillary Information Facility

prediCkt has the following command line arguments

```
-furnish support_data
-spec ck_specs
-ck outfile
-tol fit_tolerance [units]
-<sclk|newsclk> sclk_kernel
```


- '-furnish', '-spec' and '-ck' are used to specify the input metakernel, input attitude specification file and output CK file
- '-tol' is used to specify the tolerance to which the orientation stored in the CK should match the specified attitude profile
- '-sclk' or '-newsclk' specify the name of an existing SCLK or the new "fake" SCLK to be created for use with the output CK



PREDICKT - Furnsh and Spec Files

Navigation and Ancillary Information Facility

- A "FURNSH" kernel lists SPICE kernels that are to be used by prediCkt to determine geometry needed to compute orientations
- A prediCkt attitude specification (spec) file, using the text kernel syntax, is used to provide three types of information:
 - specification of dynamic directions
 - specification of orientations based on these directions
 - specification of the schedules defining when those orientations should be followed
- The contents of the FURNSH kernel and the spec file are included in the comment area of the output CK file




PREDICKT - Directions

Navigation and Ancillary Information Facility

- Dynamic directions can be of the following types
 - Based on ephemeris (position vectors, velocity vectors)
 - Fixed with respect to a reference frame (expressed as a Cartesian vector or specified by RA and DEC)
 - Towards sub-observer point
 - Based on the surface normal and lines of constant latitude or longitude
 - Based on other, already defined directions (rotated from them, computed as cross products using them, etc)
- Example: these two sets of keyword assignments specify nadir and spacecraft velocity directions for the M01 spacecraft

```
DIRECTION SPECS
                    += ( 'ToMars = POSITION OF MARS -' )
DIRECTION SPECS
                                   'FROM M01
                    += (
DIRECTION SPECS
                                     'CORRECTION NONE'
                    += (
DIRECTION SPECS
                    += ( 'scVelocity = VELOCITY OF M01
DIRECTION SPECS
                                     'FROM MARS
                    += (
DIRECTION SPECS
                                     'CORRECTION NONE'
                    += (
```



PREDICKT - Orientations

Navigation and Ancillary Information Facility


- An orientation is specified by:
 - defining that one of the frame's axes (+X,+Y,+Z,-X,-Y,-Z) points exactly along one of the defined directions
 - defining that another of the frame's axes points as closely as possible to another defined direction
 - » The third axis is the cross product of the first two
 - specifying the base frame with respect to which the orientation of this "constructed" frame is to be computed
- Example: these keyword assignments specify the nominal nadir orientation for the THEMIS instrument, flown on the M01 spacecraft

```
ORIENTATION_NAME += 'CameratoMars'

PRIMARY += '+Z = ToMars'

SECONDARY += '+Y = scVelocity'


BASE FRAME += 'J2000'
```



PREDICKT - Schedules (1)

Navigation and Ancillary Information Facility


- A schedule is defined by specifying a series of time intervals during which a given orientation is to be followed
 - For each interval for a given CK ID, the spec file defines the orientation name, start time, and stop time (as Ephemeris Times)
- Example: these spec file keyword assignments specify a schedule with a single window during which M01 (Mars Odyssey) will yield nadir-pointed orientation for the THEMIS instrument



PREDICKT - Schedules (2)

Navigation and Ancillary Information Facility


- In the example on the previous slide:
 - the CK-FRAMES keyword specifies the CK ID to be used in the output CK
 - » This ID is incorporated into the keywords defining the schedule intervals
 - the CK-SCLK keyword specifies the ID of the SCLK kernel to be used in creating the CK
 - the CK-SPK keyword specifies the ID of the object, the position of which is used in applying light time correction when orientation is computed
 - the "SOLUTION TO" construct specifies that although the orientation is sought for the M01 spacecraft frame (ID -53000), it is computed for the camera frame (M01_THEMIS_IR) and then transformed to the spacecraft frame



PREDICKT - Example (1)

Navigation and Ancillary Information Facility

```
Terminal Window
$ cat m01 map nadir.prediCkt
\begindata
       DIRECTION SPECS += ( 'ToMars = POSITION OF MARS -' )
       DIRECTION SPECS += (
                                       'FROM M01
       DIRECTION SPECS += (
                                      'CORRECTION NONE' )
       DIRECTION SPECS += ( 'scVelocity = VELOCITY OF M01 -')
       DIRECTION SPECS += (
                             'FROM MARS
       DIRECTION SPECS
                         += (
                                       'CORRECTION NONE'
                       += 'CameratoMars'
       ORIENTATION NAME
       PRIMARY
                        += '+7 = ToMars'
       SECONDARY += '+Y = scVelocity'
       BASE FRAME
                        += 'J2000'
       CK-SCLK
                        = 53
                         = -53
       CK-SPK
       CK-FRAMES += -53000
       CK-53000ORIENTATION += 'SOLUTION TO M01 THEMIS IR = CameratoMars'
       CK-53000START += @2004-FEB-10-00:00
       CK-53000STOP += @2004-FEB-15-00:00
\begintext
```



PREDICKT - Example (2)

Navigation and Ancillary Information Facility

```
Terminal Window
$ cat m01 map nadir.furnsh
\begindata
  KERNELS TO LOAD = ( 'naif0007.tls'
                       'm01 v26.tf'
                       'mar033-5.bsp'
                       'm01 map rec.bsp'
                       'm01.tsc')
\begintext
$ prediCkt -furnish m01 map nadir.furnsh -spec m01 map nadir.prediCkt -ck m01 map nadir.bc -tol
0.01 degrees -sclk m01.tsc
Begin Segment: 1 --- SOLUTION TO M01 THEMIS IR = CameratoMars
Constructing Segment
From: 2004 FEB 10 00:00:00.000
To : 2004 FEB 15 00:00:00.000
  Percentage finished: 0.0%
  Percentage finished: 5.0 %
                                  (50 quaternions)
  Percentage finished: 95.0 % (925 quaternions)
$
```